

TSI VENTURI VALVE INSTALLATION INSTRUCTIONS



APPLICATION NOTE LC-130

1. Carefully unpack the valve from the shipping container in the area where it will be mounted. Verify the size and flow range of the valve by comparing the data on the valve label to the specifications listed on the schedule or architectural drawings.

Notes: *Do not carry the valve by the linkage, cone bracket, or any other control aspects that are mounted onto the valve body.*

*The central cone shaft extends out of the valve body inlet opening when in full open position.
Do not stand the Venturi Valve on inlet opening side when the Venturi Valve is in full open position.*

2. Verify the cone direction by checking the calibration data label mounted on the cone and comparing the arrow on the label to the direction of cone travel. The cone should move freely in the direction that the arrow is pointing.
3. Check the valve action by moving the cone by hand to ensure free travel in the orientation that the valve will be mounted in (vertical or horizontal).



Note: *If the valve is configured and calibrated for horizontal or vertical operation, the valve must be level when mounted in the ductwork to operate precisely.*

TSI		500 CARDIGAN ROAD SHOREVIEW, MN. 55126-3996 Phone: 651-483-0900 Fax: 651-490-3824	HORIZONTAL INSTALLATION ONLY
AIR			
MODEL NO. VVT108MHAXXZCX			
REF. : 4500017577	JOB LV842D		
CFM : 60/500			
LOC. : CORNELL			
TAG : CORNELL			
VARIABLE VOLUME			
0 V. (MIN)	60	CFM	
2 V.	87	CFM	
4 V.	145	CFM	
6 V.	224	CFM	
8 V.	352	CFM	
10 V. (MAX)	500	CFM	
CONSTANT VOLUME			
SET POINT			
		CFM	
VERIFIED <input checked="" type="checkbox"/> INIT. <i>W.G.</i> CODE: <i>26-05</i>			




- When mounting the valve in the ductwork, support the ductwork within 12 inches of the valve. Do **not** crimp or deform the valve ends. Make sure the actuator linkage rotates freely and does not interfere with any obstruction (the cone shaft extends out of the valve inlet opening in full open actuator position). It does not matter if the actuator and linkage is up, down or sideways. However, for future maintenance or adjustment, the linkage is best positioned facing down.

Note: *Before mounting the valve to the ductwork, verify the direction of flow within the duct and align the valve accordingly.*

For Slip-In Valves

- Connect the inlet side of the valve to the ductwork using industry accepted mounting or connection practices such as drawband or bolting.

Note: *No ductwork should be mounted inside the valve. Ductwork extending into the valve could interfere with valve operation.*




- Connect the outlet side of the valve to the ductwork using industry accepted mounting or connection practices such as drawband or bolting.

Note: *No ductwork should be mounted inside the valve. Ductwork extending into the valve could interfere with valve operation.*

For Valves with Flanges

- Connect the flange on the inlet side of the valve to the ductwork flange using industry standard mounting nuts, bolts, washers and gasket material.

Note: *The Venturi Valve flange companion ring is provided by others.*



- Connect the flange on the outlet side of the valve to the ductwork flange using industry standard mounting nuts, bolts, washers and gasket material.
- Seal all the ductwork connections and verify that no leaks are present.
- Refer to the controller installation instructions for correct wiring information.

WARNING: TSI Venturi Valves are intended for indoor installation only.



UNDERSTANDING, ACCELERATED

TSI Incorporated – Visit our website www.tsi.com for more information.

USA	Tel: +1 800 874 2811	India	Tel: +91 80 67877200
UK	Tel: +44 149 4 459200	China	Tel: +86 10 8251 6588
France	Tel: +33 4 91 11 87 64	Singapore	Tel: +65 6595 6388
Germany	Tel: +49 241 523030		