INSTALLATION INSTRUCTIONS


MODEL 8630


CFM OPTION

Installing with the Model 8630 PresSura Monitor

The purpose of these instructions is to guide the installer through the installation of the optional TSI flow station and pressure transducer. The complete Model 8630 PRESSURA installation is covered in the *Model 8630 Room Pressure Installation Instructions*. Make sure drawing used for wiring matches Digital Interface Module (DIM) part number being installed.

The CFM option must be wired per the figure below. Wire should be 22 AWG or larger (supplied). Any modification to the wiring may damage the transducer and Digital Interface Module.






DIGITAL INTERFACE MODULE (DIM)

Figure 1: P/N 800245 Flow Wiring



TSI and TSI logo are registered trademarks of TSI Incorporated. PresSura is a trademark of TSI Incorporated.



DIGITAL INTERFACE MODULE (DIM)

Figure 2: P/N 800246, 800247 Exhaust Flow Wiring




Figure 3: P/N 800247 Supply Flow Wiring

This concludes installation of the CFM option. If you need assistance installing the Digital Interface Module, see the *Model 8630 PresSura Installation Instructions*. If you need further assistance, contact your local representative or TSI at 1-800-874-2811.



TSI Incorporated - Visit our website www.tsi.com for more information.

USA	Tel: +1 800 874 2811	India	Tel: +91 80 67877200
UK	Tel: +44 149 4 459200	China	Tel: +86 10 8251 6588
France	Tel: +33 491 11 87 64	Singapore	Tel: +65 6595 6388
Germanv	Tel: +49 241 523030		