

# QUICK START GUIDE

## LOW PRESSURE MEASUREMENT KIT

### 5200 SERIES

---



P/N 6011711, REV. B  
APRIL 2019






---

TSI and TSI logo are registered trademarks of  
TSI Incorporated.



## 5200 Series Low Pressure Measurement Kit (5200-LPMK)

### Components

| Description  | Quantity  | Picture   |
|--|-----------|---|
| 3/8 inch Tee Fitting with 1/8 inch barb            | 2         |  |
| 1/4 inch Tee Fitting with 1/8 inch barb            | 2         |  |
| Tubing 1/8 inch ID x 1/4 inch OD                   | 96 inches |  |
| Tubing 3/8 inch ID x 1/2 inch OD (4-inch pieces)   | 2         |  |
| Tubing 3/16 inch ID x 5/16 inch OD (4-inch pieces) | 2         |  |

## Assembly with 3/8 inch Tee Fitting

*Meter Setup: 3/8 inch or 10 mm Tube Ends*

1. Use a supplied 4-inch piece of 3/8 inch ID x 1/2 inch OD tubing or cut a piece to fit your desired length.
2. Connect the tubing from the Meter tube end to the 3/8 inch Tee Fitting with the barb facing up.
3. Measure and cut a length of 1/8 inch ID x 1/4 inch OD tubing and connect it from the Tee Fitting barb to the (+) port on the Multi-Meter.



## Assembly with 1/4 inch Tee Fitting

### *Meter Setup: 1/2 inch Tube Ends*

1. Use a supplied 4-inch piece of 3/16 inch ID x 5/16 inch OD tubing or cut a piece to fit your desired length.
2. Connect the tubing from the Meter tube end to the 1/4 inch Tee Fitting with the barb facing up.
3. Measure and cut a length of 1/8 inch ID x 1/4 inch OD tubing and connect it from the Tee Fitting barb to the (+) port on the Multi-Meter.

