


## PRESSURA™ Model 8631-HM LonWorks Object



### LonWorks Room Controller Status Definitions


#### nvoControlStatus

Bit	Description
0	Negative Mode
1	Positive Mode
2	No Isolation Mode

Setting nviRequest.object\_request to RQ\_CLEAR\_ALM clears the current alarm from the controller and the BAS

#### nvoStatusIndex

Bit	Description
0	Normal
1	Low Alarm
2	High Alarm
3	Minimum Flow Alarm
4	Data Error



**LonWorks Room Controller Room Mode Definition**

<b>nviRoomMode</b>	
<b>Bit</b>	<b>Description</b>
0	Negative Mode
1	Positive Mode
2	No Isolation Mode



**TSI Incorporated**  
 500 Cardigan Road  
 Shoreview, MN 55126 U.S.A.  
 Tel: 651 490 2811  
 800 874 2811  
 Fax: 651 490 3824  
 E-mail: answers@tsi.com