

# DIFFERENCES IN MASS MEASUREMENT READINGS WHEN COMPARING PHOTOMETRIC BASED INSTRUMENTS

APPLICATION NOTE EXPMN-019 (A4)

---

## Introduction

When comparing the readings of two or more photometric based instruments, which are all theoretically sampling the same aerosol, one may notice that the mass concentration reading of one of the instruments is significantly different than that of the other(s). For this paper a significant difference is defined as being greater than  $\pm 50\%$ . Upon seeing this type of difference, an assumption might be made that a failure has occurred in one of the instruments. To rule out instrumentation failures, TSI recommends comparing the readings from two or more instruments within the same product family, because the instruments share the same optics and will provide similar results. For example, comparing mass concentration readings between multiple SidePak™ AM520 Personal Aerosol Monitors that are sampling from the same aerosol.

---

## Further Background and Reasoning

Gravimetric mass sampling is generally considered to be the reference for mass measurements throughout the world. Photometers are great real-time instruments that estimate mass. Photometers are very dependent on a variety of parameters, including aerosol size, refraction, flow rate through the instrument, internal optics, etc. Every make and model of photometer is different. TSI Dust Monitors (i.e., DustTrak™ Monitors and SidePak Monitor Models AM520 and AM510) are calibrated back to a “standard” aerosol—Arizona Road Dust 1 (ARD1). Any aerosol other than ARD1 will have different responses. For these reasons, DustTrak Monitors and SidePak AM520 and AM510 Personal Exposure Monitors will most likely read differently when measuring any other aerosol, other than ARD1.

These products were designed to be mainly used in two ways.

1. First, it is recommended that a study be performed to calculate a Custom Calibration Factor (CCF) for a specific area and aerosol. After calculating, the CCF can be entered into the instrument to be used while taking measurements and estimating mass. Refer to the manuals for each of the TSI instruments listed above for a step-by-step process of creating and adding CCFs to the mass measurements.
2. Second, as a comparative measurement, baseline measurements are taken of an area. After a baseline reading is established, action is taken (i.e., increased ventilation or filtration) and a subsequent measurement is taken, anticipating an improvement in mass measurement. Mass measurements using TSI instruments cannot be considered a reference—noting that one type of TSI instrument cannot serve as a reference for another TSI instrument.



---

## An Option for Getting Instruments to Match

If users have been using certain instruments as a standard (not a reference) for a specific application, and it is preferred a new product match the current product, a CCF must be entered. A CCF can be found by either:

- a) Conducting gravimetric analysis for the new instrument, if the existing instrument was calibrated to a gravimetric sample, or
- b) Taking measurements with both instruments over a 30–60 minute period and comparing the data to develop a new CCF for the new instrument.

Option (b) does not provide a better understanding of the specific aerosol but can be a quick method to simply get the instruments to match.

---

## Updating the CCF for the SidePak AM520 Monitor

As an example, the following describes the procedure for adjusting the CCF for the SidePak AM520 Monitor. Refer to the Calibration section of the SidePak AM520 Monitor User Guide which was provided new with the instrument. Within the Calibration section, find the User Cal heading.

Procedure for selecting the calibration factor through the SidePak AM520 Monitor user interface:

1. Under **MAIN MENU**, use the ▲ ▼ keys to scroll to **CALIBRATIONS** and press ↵.
2. Under **CALIBRATION** menu, use the ▲ ▼ keys to select **USER CAL** and press ↵.
3. Under **USER CAL**, use the ▲ ▼ keys to select the calibration you want and then press ↵ to confirm the setting.
  - User Cal 1 (Factory) is set to 1.00 by TSI and cannot be adjusted.
  - User Cal 2 (Ambient) is set to 0.38 by TSI and cannot be adjusted.
  - User Cal 3 to 7 default to 1.00 and can be adjusted from 0.10 to 10.00 through TrakPro™ Data Analysis Software.
  - User Cal 3 to 7 can be changed in the field through the AM520/AM520i menu, after pressing ↵ to select the desired factor, adjust the value of the cal factor using the ▲ ▼ keys. Press the ↵ key again to accept the changes and return to the **CALIBRATION** Menu.

---

## Conclusion

It is not uncommon for photometric based instruments to provide different results, when sampling the same aerosol. Photometer measurements are very dependent on a variety of parameters, including aerosol size, refraction, flow rate through the instrument, internal optics, etc. Keep this in mind when comparing instruments that are not in the same product family and when the instruments do not share the same manufacturer. If you believe an error has occurred with use of a TSI instrument, please contact a TSI Technical Service Representative at 1-800-874-2811 or by filling out the required information at <http://www.tsi.com/Support/>.



UNDERSTANDING, ACCELERATED

TSI Incorporated – Visit our website [www.tsi.com](http://www.tsi.com) for more information.

USA Tel: +1 800 874 2811  
UK Tel: +44 149 4 459200  
France Tel: +33 1 41 19 21 99  
Germany Tel: +49 241 523030

India Tel: +91 80 67877200  
China Tel: +86 10 8219 7688  
Singapore Tel: +65 6595 6388