

# MITA MASK ADAPTER KIT MODEL 8125-01

---

INSTRUCTION GUIDE



APPLICABLE MASK MODELS:  
M40/FR-M40, M45, MCU-2/P AND MILLENNIUM



## Included Accessories

<p><b>Drink Tube (DT) Valve Adapter</b></p> <ul style="list-style-type: none"> <li>➤ Installed on mask during DT Flow test</li> </ul>	
<p><b>40/74 mm Mask Filter Plug</b></p> <ul style="list-style-type: none"> <li>➤ Installed on mask during <b>Protection Factor</b> test</li> </ul>	
<p><b>Exhalation Valve (EV) Adapter</b> (for M40, FR-M40, MCU-2/P, and Millennium masks)</p> <ul style="list-style-type: none"> <li>➤ Connect to Mask Exhalation Valve during <b>EV Leak</b> test</li> </ul>	
<p><b>Exhalation Valve (EV) Adapter</b> (for M45 masks)</p> <ul style="list-style-type: none"> <li>➤ Connect to Mask Exhalation Valve during <b>EV Leak</b> test</li> </ul>	
<p><b>EV Self Check Zero Fixture</b></p> <ul style="list-style-type: none"> <li>➤ Connect to EV Adapter, during the <b>EV Leak Zero Test</b> option of the Self Checks procedure</li> </ul>	

### Note

The Exhalation Valve (EV) Leak Test is to be excluded from the M45 mask test protocol. The EV leak Test should be disabled and the EV Adapter, displayed above, should be in place during the Mask Protection Factor test.

# Components Installed on Masks



**Example of M40 / FR-M40**



**Example of M45**



**Example of MCU-2/P**



**Example of MILLENNIUM**



UNDERSTANDING, ACCELERATED

**TSI Incorporated** – Visit our website [www.tsi.com](http://www.tsi.com) for more information.

**USA** Tel: +1 800 874 2811  
**UK** Tel: +44 149 4 459200  
**France** Tel: +33 4 91 11 87 64  
**Germany** Tel: +49 241 523030

**India** Tel: +91 80 67877200  
**China** Tel: +86 10 8219 7688  
**Singapore** Tel: +65 6595 6388