VELOCICALC® ROTATING VANE ANEMOMETER MODEL 5725

The VelociCalc® 5725 is a high performance, yet simple to use, rotating vane anemometer. High accuracy and reliability make the VelociCalc 5725 the professional's ideal tool for measuring unevenly distributed or fluctuating flows through heating and cooling coils, grilles, and filters.

It accurately measures air velocity and temperature, calculates flow rate, performs averaging, and can determine minimum and maximum readings. Using sweep mode, you can quickly provide one averaged reading of velocity or volume over a large measurement area. The large vane head automatically averages and dampens velocity and volume readings. The VelociCalc 5725 includes variable time constant, sampling and statistics functions and data logging capability.

Applications

- + Heating and cooling coil analysis
- + Grille measurements
- + Face velocity measurements
- Filters
- Kitchen exhausts

Features and Benefits

- + Reversible 4 in. (100 mm) head to read supply and exhaust flows
- + Calculates volumetric flow rate when user inputs duct shape and size, or area
- + Sampling function records multiple point measurements
- + Automatic averaging of air velocity
- + Simultaneously displays velocity and temperature
- + Sweep mode for one overall measurement
- + Optional 36 in. telescopic probe available
- + Compatible with optional Aircone flow hoods

Data Logging Features

- + Logs 12,700+ samples with a time and date stamp
- + Recall, review, store data
- + LogDat2[™] downloading software included



UNDERSTANDING, ACCELERATED

SPECIFICATIONS

VELOCICALC® ROTATING VANE ANEMOMETER MODEL 5725

Velocity

Range Accuracy 50 to 6,000 ft/min (0.25 to 30 m/s) ±1.0% of reading ±4 ft/min (±0.02 m/s)

Duct Size Range

0 to 500 ft² (0 to 46.45 m²)

Volumetric Flow Rate

Range

Actual range is a function of velocity and duct area

Temperature

Range Accuracy Resolution 40 to 113°F (5 to 45°C) ±2.0°F (±1.0°C) 0.1°F (0.1°C)

Instrument Temperature Range

 Operating (Electronics)
 40 to 113°F (5 to 45°C)

 Storage
 -4 to 140°F (-20 to 60°C)

Data Storage CapabilitiesRange12,700+ samples and 100 test IDs

Logging Interval 1 second to 1 hour

Time Constant User selectable

External Meter Dimensions (H x W x D) 3.3 in. x 7.0 in. x 1.8 in. (8.4 cm x 17.8 cm x 4.4 cm)

Meter Weight with Batteries 0.6 lbs (0.27 kg)

Power Requirements

Four AA-size batteries or optional AC adapter

Aircone Flow Hoods

Aircone Flow Hoods are a fast and accurate method of maximizing the usefulness of your



4 in. (100-mm) rotating vane anemometers. For a modest investment, you can enhance the capability of your rotating vane, turning it into an air volume flow balancing tool.

Features and Benefits

- + Rectangular and circular cones available
- + Measures volumetric flow at grilles, diffusers, and linears
- + Reads air volume quickly and accurately
- + Excellent choice for small grilles

TSI Aircone Flow Kit (p/n 801749) includes one each:

Rectangular Round Range 11.2 in. x 9.2 in. (285 mm x 235 mm) 7.1 in. (180 mm) diameter 0 to 210ft³/min (0 to 100 l/s, 0 to 360 m³/h)

Accessories

801748

Telescopic articulated extension 1.3 to 3.6 ft (0.4 to 1.1 m)

Specifications are subject to change without notice.

TSI, the TSI logo and VelociCalc are registered trademarks, and LogDat2 is a trademark of TSI Incorporated.



UNDERSTANDING, ACCELERATED

TSI Incorporated - Visit our website www.tsi.com for more information.

 USA
 Tel: +1 800 874 2811
 India
 Tel: +91 80 67877200

 UK
 Tel: +44 149 4 459200
 China
 Tel: +86 10 8219 7688

 France
 Tel: +33 4 91 11 87 64
 Singapore
 Tel: +65 6595 6388

 Germany
 Tel: +49 241 523030
 Tel: +65 6595 6388

©2013 TSI Incorporated